

Automatic deactivation of tags
Software user manual

1. Use the USB interface to connect the USB reader to the PC
Check through the device manager of your computer to which com-port number to connect the USB reader.

If the reader is not detected as a com-port, install the driver included in the distribution on your computer.

2. Open the software, select the com-port connection number,
Enter the initialization password, if "LOCK" is selected, the password will be blocked.
Ex: 1234567F
3. Enter 00000000 in the field and click Star.
4. You can minimize the application in the background mode. Tags will be automatically deactivated if you bring the tag to the reader. You will hear the deactivator beep each time the tag will be deactivated.

The demo as below:

